ARTECK®

User Manual

Arteck MW167 Wireless Mouse

RoHS CE UKCA FC 204-620131

2 Years Warranty Claim: support@arteck.com

Welcome

Thank you for choosing this Arteck MW167 wireless mouse. To ensure optimum performance and safety, please read these instructions carefully before operating this product. It is strongly recommended you keep the manual for future reference.

Product Specifications

Wireless Specification	2.4G USB Wireless
Operating Range	Up to 10 Meters
Moldulating System	GFSK
Operating Voltage	3.0-4.2V
Operating Current	＜2.5mA
Standby Current	0.3-0.5mA
Sleeping Current	＜40uA
Charging Current	＞200uA
Standby Time	＞100 days
Charging Time	＞2 hours
Input Voltage	5V
Uninterrupted Working Time	＞64 hours
Battery Style	USB Rechargeable
Lithium Battery Specification	3.8*20*35mm
Key Strength	50-80g
Key Life	3 million strokes
Operating Temperature	-10 - 50℃

Package Contents:

Arteck MW167 Wireless Mouse *1
USB receiver (stored inside the back of mouse) *1
USB-C charging cable *1
User manual *1

Getting Started Guide

1. Product Overview



① Mouse ON/OFF Slide Switch
② Mouse DPI Switch: Press the button to switch the DPI between 800/1200/1600/2000/2400 DPI.
③ Backward Button: Control to backward in web or folder.
④ Forward Button: Control to forward in web or folder.
⑤ Windows Switch Button: Press the button to switch between different windows.
⑥ Mouse Indicator: Lights up red for about 3 secs when being turned on.
Red light will turn on when the mouse is charging and turn to green after full charged.
Flashing when in pairing mode.
Flashing when the battery of the mouse is low.
DPI indicator: After pressing the DPI button, the indicator will be changed between 800/1200/1600/2000/2400 DPI.
When the mouse indicator flash one time after pressed, the mouse is 800 DPI, flashing 2 times means DPI is 1200 DPI, flashing 3 times means 1600 DPI, flashing 4 times means 2000 DPI, flashing 5 times means 2400 DPI.
⑦ USB-C Charging Port: Used for charging the mouse.
⑧ USB Receiver: The USB receiver is stored at the back of the mouse, which is required to insert to the USB port.

2. DPI Key

Press the DPI key, the indicator will be flashing. The indicator flashing 1 time means the DPI change to be 800 DPI, the cursor motion speed will be slow. Press the DPI key again, the indicator will be flashing. The indicator flashing 2 time means the DPI change to be 1200 DPI, the cursor motion speed will be a bit faster. Press the DPI key again, the indicator will be flashing. The indicator flashing 3 time means the DPI change to be 1600 DPI,the cursor motion speed will be medium. Press the DPI key again, the indicator will be flashing. The indicator flashing 4 time means the DPI change to be 2000 DPI, the cursor motion speed will be much faster. Press the DPI key again, the indicator will be flashing. The indicator flashing 5 time means the DPI change to be 2400 DPI, the cursor motion speed will be the fastest.

Steps of Pairing with Your Computer

Step 1: Turn on the switch at the back of the mouse.
Step 2: Insert the USB receiver (stored inside the back of the mouse) to the port of your computer. It will auto pair to mouse. You are able to use the mouse right now.
Notice: If you are not able to connect the mouse to your computer, please kindly contact with support@arteck.com for assistance. We will solve your issue with 100% satisfactory solution.

Charge the Battery of the Mouse

Turn on the Wireless Mouse.
The mouse power indicator light (red) will illuminate for 3 seconds and then turn off to save power. Your mouse is still on.
If the mouse indicator keep blinking or the mouse is not working, it means the mouse is out of power, you need to charge the mouse.
1. Plug the USB-C charging cable into the mouse at the top.
2. Plug the USB plug on a computer or any cellphone USB power adaptor.
3. Charge for 2-4 hours, or until the indicator of the mouse become green.

ⓘ Caution:

1. When not in use for a prolonged period, it is recommended that you turn off he mouse to lengthen battery life.
2. When the power status light flash, it is recommended that charging the mouse in 2 hours.

Energy-saving Sleep Mode

Mouse's long life battery lasts for several months of normal use. The mouse will go into sleep mode if left on and not being used; press the button on the mouse and wait a second or two to bring it out of sleep mode. The mouse won't be able to move the cursor while in sleep mode, you need to press the button on the mouse to wake it up then it will be able to move.

⚠Safety Caution

1. Keep the item away from sharp objects.
2. Do not place heavy object on the mouse.
3. Away from microwave items.
4. Do not force or distorted the mouse.
5. Keep away from oil, chemical or other organic liquid.

Cleaning

Clean the mouse with water, alcohol or alcohol based disinfectant.

Troubleshooting

1. Make sure the mouse is on (slide switch in "ON" position).
2. Make sure the mouse is in operating distance (within 10 meters).
3. Ensure the battery storage has power.
4. Make sure the USB receiver is plugged to the PC correctly.
5. If you are not able to move the cursor, please press the button to wake up the mouse.

Warranty

Our company provides customers with a warranty of 24 months from the date of purchase.

Contact Us

For any inquires or comments concerning our products, please send an email to support@arteck.com, and we will respond to you as soon as possible. If there is any quality-related issue with the product, you may request a replacement or refund by submitting a request to support@arteck.com.

ARTECK®

ユーザーマニュアル

Arteck MW167 ワイヤレスマウス

RoHS CE UK CA FC R 204-620131

保証対応: support@arteck.com

ようこそ

Arteck MW167ワイヤレスマウスをお選びいただきありがとうございます。
本商品を作動させる前に、最高のパフォーマンスを発揮させ安全にお使いいただくために説明文をお読みください。このマニュアルは手元に保管していただくことを強く推奨します。

商品の仕様

ワイヤレス方式	2.4G USBワイヤレス
通信範囲	最大10M
変調システム	GFSK
稼働電圧	3.0-4.2V
稼働電流	＜2.5mA
待機電流	0.3-0.5mA
スリープ電流	＜40uA
充電電流	＞200uA
待機時間	>100 日
充電時間	>2時間
充電電圧	5V
連続使用可能時間	>64時間
電池タイプ	USB充電式
リチウム電池仕様	3.8*20*35mm
キー圧力	50-80g
キー寿命	ストローク300万回
移動温度	-10 - 50℃

パッケージ内容:

Arteck MW167 ワイヤレスマウス x 1
USBレシーバー(マウスの裏面に収める) x 1
USB Type-C 充電ケーブルx 1
ユーザーマニュアル x 1

1. ワイヤレスキーボードとマウスの使い方



① マウス電源スイッチOn/Off
② マウスDPIボタン:このボタンを押すと、マウスのDPIが800/1200/1600/2000/2400 DPIの間に変更されます。
③ 戻るボタン: Webブラウザに一つ前のフォルダに移動します。
④ 進むボタン: Webブラウザに一つ先のフォルダに移動します。
⑤ このボタンを押して開いているアプリ間で切り替えます。
⑥ マウス表示灯:マウスの電源スイッチをオンにて、表示灯は3秒ほど赤色に点灯して、後節電モードになり消えます。マウスが正常に動作できます。
マウスが充電している時、表示灯が赤色に点灯して、充電完了したら緑色に点灯になります。
マウスの電池残量がなくなってきた時表示灯が点滅してます。
DPI表示灯: DPIボタンを押すと、マウスのDPIが800/1200/1600/2000/2400 DPIの間に変更されます。
DPIボタンを押して、
表示灯が一回に点滅すれば、マウスが800 DPIになります。
表示灯が二回に点滅すれば、マウスが1200 DPIになります。
表示灯が三回に点滅すれば、マウスが1600 DPIになります。
表示灯が四回に点滅すれば、マウスが2000 DPIになります。
表示灯が五回に点滅すれば、マウスが2400 DPIになります。
⑦ USB Type-C充電ポート:マウスを充電する時に使用します。
⑧ USBレシーバー:マウスの裏面に収めます。USBレシバーがデバイスのUSBポートに差し込む必要です。

2. DPIボタン

DPIボタンを押すと、マウス表示灯が点滅します。表示灯が一回に点滅して、マウスのDPIが800 DPIになり、カーソルの移動は最低速です。DPIボタンをもう一度押すと、表示灯が二回に点滅してDPIが1200DPIに変更になり、カーソルの移動は低速です。DPIボタンをもう一度押すと、表示灯が三回に点滅してDPIが1600DPIに変更になり、カーソルの移動は中速です。DPIボタンをもう一度押すと、表示灯が四回に点滅してDPIが2000DPIに変更になり、カーソルの移動は高速です。DPIボタンをもう一度押すと、表示灯が五回に点滅してDPIが2400 DPIに変更になり、カーソルの移動は最高速です。

パソコンとのペアリングの手順

ステップ1: マウス裏面の電源スイッチをオンにします。

ステップ2: パソコンのUSBポートにUSBレシーバー(マウスの裏面に収める)を挿入します。マウスが自動的にペアリングされます。この時、マウスが使えます。

ご注意：マウスがパソコンとペアリンクできない場合は、お気軽にsupport@arteck.com ご連絡くださいますようお願い申し上げます。弊店はぜひご満足いただけるアフターサービスをご提供いたします。

マウス電池の充電

マウスの裏面の電源スイッチをオンにします。表示灯が3秒ほど赤色に点灯して、後節電モードになり消えます。マウスが正常に動作できます。

マウスの表示灯が点滅すればまたはマウスが使用できない場合は、低電量を表示して、マウスの充電が必要です。

1. 付属のUSB Type-Cケーブルをパソコンの USBコネクタまたはACアダプターに接続します。
2. USBケーブルのもう一方をマウスのMicro充電コネクタに差し込みします。
3. 2-4時間に充電してください、またマウスの表示灯が緑色に点灯になるまでに充電してください。

お使う中のご注意

1. 長時間にご使用しない場合があれば、バッテリの寿命を延ばすためにマウスの電源スイッチをオフしてください。
2. バッテリ表示灯が点滅している場合は、2時間以上マウスを充電してください。

電力を低減するスリープモードについて

マウスは通常の使用においては、バッテリ電量が数月間に使用できます。長時間使用していないとスリープモードに入ります。マウスを押して数秒後、スリープモードを解除します。マウスはスリープモードに入ると、カーソルを動かすことができません。マウスの左鍵または右鍵を押してスリープモードを解除して、マウスが正常に操作できます。

安全上の注意

1. 鋭いものから遠ざけて保管してください。
2. マウスの上に重い物を置かないでください。
3. 電子レンジから遠ざけてください。
4. マウスに力を込めたり曲げようとしないでください。
5. 油、化学物質または有機溶剤から遠ざけて保管してください 清潔水、アルコール或いはアルコール類洗剤を使ってマウスを清潔ください。

トラブルシューティング

1. マウスをオンになっていることを確認してください (裏面の電源スライドスイッチがONの位置になること)。
2. マウスが10メートル範囲内使用されていることを確認してください。
3. バッテリの残量が空になっていないかを確認してください。
4. USBレシーバーをパソコンのUSBポートにちゃんと接続します。
5. カーソルを動かすことができない場合は、マウスの左鍵または右鍵を押して、スリープモードを解除します。

保証

購入日から24ヶ月間保証。

お問い合わせ

当社製品に関するご質問やご意見につきましては、support@arteck.comに宛ててメールを送信していただくと、迅速に返信を差し上げます。製品の品質に関して問題があれば、support@arteck.com.に交換または返金要求を送信してください。